

# UŽIVATELSKÝ MANUÁL

**ZFISH**  
FOR A BETTER CATCH

*Merkur* WIRELESS

## SADA SIGNALIZÁTORŮ ZÁBĚRU 2+1 (3+1)

SIGNALIZÁTOR ZÁBĚRU



### SIGNALIZÁTOR ZÁBĚRU:

- 1 Zapnutí/vypnutí – zmáčkní a podrž 3 sekundy
- 2 Ovládání hlasitosti – krátce stiskni pro změnu úrovně (5 možností)
- 3 Nastavení citlivosti – 4 možnosti
- 4 Nastavení tónu – 4 možnosti
- 5 LED dioda

PŘIJÍMAČ



### PŘIJÍMAČ:

- 1 Zapnutí/vypnutí – zmáčkní a podrž 3 sekundy
- 2 Ovládání hlasitosti – krátce stiskni pro změnu úrovně (5 možností včetně vibrace)
- 3 Kódovací tlačítko
- 4 Barevné LED diody

### INSTALACE BATERIÍ:

Nainstalujte 12V baterii do každého hlásiče a 3× AAA 1,5V baterii do přijímače posunutím krytu baterie na zadní straně každé jednotky.

### PÁROVÁNÍ SIGNALIZÁTORŮ A PŘIJÍMAČE:

Na vypnutém přijímači zmáčkněte a podržte boční kódovací tlačítko (3). Současně zapněte přijímač (rozsvítí se dioda). Opětovným mačkáním kódovacího tlačítka (3) si vyberte požadovanou barvu. Poté „zapípejte“ signalizátorem. Příposlech vydá zvukový signál, který potvrdí úspěšné spárování.

### DOSAHI:

100–150 metrů, podle okolností terénu.

### INDIKACE SLABÉ BATERIE:

Když bude baterie v signalizátoru slabá, ozve se krátký zvukový signál doprovázený blikáním LED kontrolky. Když bude slabá baterie přijímače, ozvou se opakované krátké zvukové signály.

### NOČNÍ POZIČNÍ SVĚTLO (HLÁSIČE):

Ujistěte se, že je hlásič zapnutý. Poté dlouze držte tlačítko S (3) a současně krátce stiskněte tlačítko T (4).

### ÚDRŽBA:

Po každém použití otřete hlásiče i přijímač. Odstraňte vlhkost a nečistoty kouskem čisté suché látky. Při delším nepoužívání vyjměte baterie.

### Dovozce a distributor:

Zfishing Sport Wholesale s.r.o., Za Mototechnou 1375/7, 155 00, Praha 5

**E-shop:** [www.zfishingsport.cz](http://www.zfishingsport.cz), tel. 235 311 522

**Technická podpora:** [info@zfishingsport.cz](mailto:info@zfishingsport.cz)

# USER MANUAL

**ZFISH**  
FOR A BETTER CATCH

## Merkur WIRELESS BITE ALARM SET 2+1 (3+1)

BITE ALARM



### BITE ALARM:

- 1 Power ON/OFF  
– press and hold 3 sec.
- 2 Volume Switch – click for volume  
adjust (5 levels)
- 3 Sensitivity Switch – 4 options
- 4 Tone Switch – 4 options
- 5 LED diod

RECEIVER



### RECEIVER:

- 1 Power ON/OFF  
– press and hold 3 sec.
- 2 Volume Switch  
– click for volume adjust  
(5 levels including vibrations)
- 3 Code Button
- 4 Multicolor LEDs

### BATTERY INSTALATION:

Install a 12V battery to each Bite Alarm and 3× AAA 1,5V battery to Receiver by sliding down the battery cover plate on the back of each unit.

### SYNCHRONISING BITE ALARMS WITH RECEIVER:

Make sure that receiver is OFF. Then press and hold Code button (3). At the same time turn ON the receiver (There will be light).

Choose your demanded colour by repeatedly pressing Code button (3).

Then simulate bite and „beep“ with alarm. Receiver will make sound signal to confirm match is completed.

### RANGE:

100–150m, depend on surrounding conditions

### LOW BATTERY DETECTION FUNCTION:

The alarm will warn you with short „beep“ when batteries of the alarm are weak with latching LED on, until LED off. The receiver will warn you with short „beep“ constantly when the batteries are weak.

### NIGHT LIGHT FUNCTION ON BITE ALARMS:

Make sure that power is ON. Then press and hold button S (3) and at the same time click on button T (4).

### MAINTENANCE:

Wipe alarms and receiver units after each use. Remove moisture and debris with a dry clean cloth. For long storage periods remove batteries.

---

### Importer & distributor

Zfishing Sport Wholesale s.r.o.  
Za Mototechnou 1375/7, Prague, Czech rep.  
[www.zfishingsport.com](http://www.zfishingsport.com)